

Vehicle Overview

1. Keys and Remote Control

The Dacia Sandero secret is used for the ignition, doors, and gas filler cap. The far flung manipulate helps you to lock and free up the car and get admission to the luggage compartment.

Press the lock button to stable the Dacia Sandero doorways and baggage compartment. The danger caution lights flash twice to verify the car is locked. Press the unlock button to free up the doorways, with the hazard lighting fixtures flashing once as confirmation.

To unlock the luggage compartment, press and keep the baggage compartment button. Depending on the automobile model, the boot can also open robotically. The far off manipulate range can range relying on the encircling surroundings. If the automobile is unlocked but no door is opened for approximately seconds, it could routinely lock again.

2. Locking and Unlocking

Dacia sandero the faraway control or card can also stop running if its battery is susceptible, the car battery is discharged, or nearby gadgets interfere with the signal.

If this occurs, you could use the Dacia Sandero emergency key constructed into the cardboard or the vehicle key to unlock the driver's door manually. Once inside the Dacia Sandero, the doorways also can be locked or unlocked the usage of the interior door manipulate.

If essential, the doorways may be locked manually with the locking mechanism on each door. When the automobile is locked from internal, the doorways can generally be opened from interior or with the important thing from the driver's door.

If the cardboard or secret is unavailable, the indoors locking transfer may be used to lock the doors and tailgate. With the engine switched off, press and hold the switch for greater than five seconds, then near the open door or tailgate to secure the car.

3. Opening and Closing the Doors

Dacia Sandero doors can be opened from out of doors while the vehicle is unlocked. Simply place your hand under the exterior door cope with and pull it in the direction of you. From inside the vehicle, pull the interior door manage to open the door.

If the Dacia Sandero headlights or outside lighting fixtures were left on after the ignition is switched off, a warning buzzer will sound when the motive force's door is opened. The car might also offer a caution when a door or the baggage compartment is open or not nicely closed.

While riding, a warning mild and audible sign can alert the Dacia Sandero driver if an opening detail remains open. For infant safety, the rear doorways may be prevented from commencing from internal with the aid of activating the child safety lock on each rear door. Always check that the doorways are securely locked before riding.

4. Seat Adjustment and Seat Belts

Dacia sandero for protection, regulate the seats simplest when the car is stationary. Move the the front seat forwards or backwards the use of the adjustment cope with, then launch it and make certain the seat is securely locked. Depending at the car, the seat height also can be adjusted. To change the seatback angle, use the seatback cope with and pick out a snug function. Avoid reclining the Dacia Sandero seatback too a long way, as this may reduce the effectiveness of the seat belt.

If geared up, heated seats may be managed with the ignition switched on. The first press activates maximum heating, the second reduces it to a decrease putting, and the third switches it off. The system mechanically regulates the temperature when heating is energetic. Before riding, sit down nicely towards the

seatback and regulate the seat distance, height, headrest and steering wheel for a snug riding position. Keep free devices faraway from the ground near the pedals, as they could intrude with braking or different controls.

Always put on a seat belt and make certain each passenger uses their personal belt. The shoulder belt must sit close to the lowest of the neck, at the same time as the lap belt should lie flat all through the thighs and pelvis. The belt have to healthy intently in the direction of the frame, without cumbersome apparel or items beneath it. Fasten the buckle securely and take a look at that it locks.

If the belt will become stuck, allow it to retract slightly earlier than attempting once more. The vehicle can also provide a seat belt reminder if the driving force or an occupied passenger seat is not sporting a belt. Depending at the automobile, rear seat belts may also be monitored. A caution mild and audible sign can alert occupants whilst a belt stays free whilst driving. Always check that all occupied seats have their belts fastened before beginning your journey.

5. Child Safety and Child Seat Installation

Dacia sandero

Child seats can be installed the usage of the vehicle seat belt or the ISOFIX device, relying at the type of seat and vehicle. Always use a baby seat this is accredited on your car and suitable for the child's size and weight. When the usage of a seat belt, ensure the belt follows the installation instructions supplied by means of the kid seat manufacturer. The belt have to not be twisted or unfastened, and the seat have to stay firmly secured while moved to and fro or backwards and forwards.

The Dacia Sandero ISOFIX system provides a secure and convenient manner to install well suited child seats. Attach the child seat to the ISOFIX anchorage factors and, in which required, join the top tether strap or support leg in line with the seat producer's commands. After set up, check that the seat is firmly locked and that nothing is blockading the anchorage factors. The Dacia Sandero ISOFIX fittings must only be used for well matched ISOFIX infant seats and need to no longer be used to connect different gadgets.

Before putting in a Dacia Sandero infant seat, take a look at the passenger airbag

fame and make certain the seat role is appropriate for the type of infant seat being used.

Rear-dealing with seats in the Dacia Sandero might also require the front seat to be moved forward to offer sufficient area, while a few installations may additionally require the rear headrest to be removed.

Always check the car and baby seat instructions before set up and ensure each infant is nicely secured earlier than riding.

6. Driving Position Left/Right

The dashboard and control vicinity contains the principle systems had to function and monitor the automobile. Depending on the model and device, it is able to consist of the ignition transfer or start button, instrument panel, steering wheel controls, horn, air vents and demister stores. The steerage column controls may be used for the outside lights, path indicators, fog lighting and windscreen or rear display wipers.

Other controls might also include the heating and air con device, hazard caution lights, relevant door locking, heated seats, ECO mode, Stop and Start, Park Assist and cruise control or velocity limiter. The automobile may also be ready with a multimedia or navigation device, accessories sockets, glove compartment, bottle holders and a gearstick or digital parking brake.

Additional controls, including bonnet launch, guidance wheel adjustment, beam height adjustment, fuse container and LPG controls, can be available relying at the vehicle model.

7. Warning and Indicator Lights

The dashboard caution lighting fixtures show the automobile's repute and warn you to viable troubles. Most lighting in short seem whilst the ignition is switched on and go out after the engine starts. The pressing prevent warning mild shows a severe trouble. Stop safely, switch off the engine and speak to an accredited provider.

The brake system caution mild can also indicate low brake fluid or a braking fault, at the same time as the ABS warning mild suggests a possible ABS trouble. The airbag warning mild may suggest a fault within the airbag device. The oil stress warning mild calls for on the spot interest—stop the engine and check the oil stage.

The battery warning mild may also indicate a charging system trouble, at the same time as the coolant temperature light warns that the engine may be overheating.

The low fuel mild approach the fuel level is low and also you should refuel quickly. The tyre stress caution mild shows incorrect or low tyre pressure, at the same time as the door caution light indicates that a door or luggage compartment may not be nicely closed

Driving

1. Starting and Stopping the Engine

[Dacia sandero](#)

To start the engine with a key, turn the ignition to the begin role without urgent the accelerator and release the important thing as soon because the engine starts. Manual vehicles may additionally require the snatch pedal to be pressed, while computerized cars need to be in P or N with the brake pedal pressed.

Diesel models can also require watching for the preheating light to exit in cold climate. LPG models begin on petrol and automatically switch to LPG while conditions are suitable. For vehicles with a begin button, press the brake or take hold of pedal after which the button. To stop the engine, make certain the car is stationary and choose P on computerized models earlier than switching it off. Never depart kids or animals by myself in the vehicle.

2. Stop and Start Function

The Stop and Start gadget enables lessen fuel consumption and greenhouse fuel emissions by way of robotically stopping the engine whilst the car is stationary, inclusive of at visitors lighting or in heavy site visitors. The machine turns on

automatically when the car is started out.

On guide automobiles, the engine may additionally prevent while the gearbox is in impartial, the snatch is released and the automobile has stopped. On automated fashions, the device can perform while the automobile is stationary with the brake pedal pressed. The engine restarts robotically whilst the driving force releases the brake, presses the accelerator or grasp, selects a gear, or when using conditions require it.

The machine might not prompt if the engine is bloodless, the battery price is low, a door or bonnet is open, opposite equipment is chosen, or the automobile wishes extra engine energy for heating or air conditioning. A warning mild or message on the device panel may also suggest when the engine is on standby or when the Stop and Start feature is unavailable.

The gadget may be deactivated the usage of the devoted transfer and may be activated once more whilst wished.

3. Gear Lever and Handbrake

To apply the handbrake, pull the lever upwards firmly and make sure the automobile is absolutely stationary. To release it, elevate the lever barely, press the release button and decrease the lever absolutely. The handbrake caution light ought to exit while it is nicely launched. When parking the Dacia Sandero on a slope, follow the handbrake firmly and, for manual vehicles, pick first or reverse tools. For automated motors, choose P.

If the automobile is driven with the handbrake no longer fully released, a warning mild and audible sign may additionally seem. When deciding on opposite equipment, ensure the vehicle is desk bound and comply with the equipment sample shown on the tools lever. Avoid hitting limitations, raised kerbs or other items below the automobile, as this could harm components along with the axle.

4. Driving Advice and ECO Driving

Fuel intake relies upon on riding conditions, vehicle device and using fashion. To improve gasoline economic system, use the gear-change indicator and select the best appropriate tools with out over-revving the engine. ECO mode helps reduce

gas intake by means of adjusting acceleration, equipment changes and different driving capabilities, and can be briefly overridden whilst extra engine energy is needed.

Avoid surprising acceleration, needless braking and maintaining excessive speeds. When coming near traffic, bends or obstacles, launch the accelerator early and allow the vehicle to sluggish evidently. On hills, avoid pressing the accelerator more than necessary. During the first few miles, force lightly until the engine reaches its ordinary working temperature in place of leaving it running while stationary.

In bad weather, power cautiously and in no way attempt to cross water that is deeper than the decrease edge of the wheel rims. Properly fitted ground mats have to additionally be used to keep away from interfering with the pedals.

5. Tyre Pressure Loss Warning

The tyre strain tracking system indicators the motive force when one or more tyres lose stress. It detects stress loss via monitoring the wheel velocity while using, and a caution light appears at the dashboard when tyre stress is simply too low or a tyre can be punctured.

Check all 4 tyres when they are bloodless and alter the strain in line with the automobile's endorsed values and present day load. The device need to be reset after inflating or adjusting the tyres, changing a wheel, or converting the wheel positions; in any other case, it could not offer an accurate caution.

Avoid depending only on the machine, mainly after fitting new or unapproved tyres, the use of snow chains, driving on slippery roads, or wearing a extensively special load. Never deflate a warm tyre, and after the use of a tyre repair or inflation package, test the strain and reset the device again.

6. Active Emergency Braking

The Active Emergency Braking device allows reduce the danger of a collision by using warning the motive force and, if important, applying the brakes mechanically. Using radar records, the device detects vehicles beforehand and also can hit upon certain oncoming cars whilst turning at a crossroads.

If a collision chance is detected, a warning appears at the tool panel with an audible alert. If the driver does no longer react, the device can growth the braking force or follow emergency braking to help keep away from or reduce the impact. The system can also perform at one of a kind speeds relying at the scenario and may not reply to every obstacle or automobile.

Keep the radar vicinity at the the front of the automobile clean and unobstructed, and do no longer cowl, adjust or paint it. The motive force must remain attentive and be prepared to brake or steer while vital, as the gadget is a riding useful resource and can not replace careful using.

Comfort

1. Manual Heating, Ventilation and Air Conditioning

The manual climate control gadget permits you to alter the cabin temperature, fan velocity and path of airflow. Turn the temperature manipulate toward the crimson location for warmer air and modify the fan pace to boom or reduce airflow. The aircon may be switched directly to cool the cabin and decrease condensation, even as air recirculation helps cool the interior quickly or maintains outside air from entering while driving through polluted areas.

For quicker demisting, pick the windscreen demist putting, use a high fan pace and permit out of doors air to go into. The heated rear display also can assist clean mist and ice from the rear window and, depending on the car, the door mirrors.

2. Automatic Climate Control

The automated climate manipulate machine maintains a snug temperature and good visibility through robotically adjusting the fan pace, airflow path, air con and air recirculation. Press AUTO and set your selected temperature; the gadget will progressively alter the airflow to reach and preserve the chosen comfort degree.

The Clear View feature speedy demists or de-ices the windscreen, front aspect windows, rear screen and, depending at the automobile, the door mirrors. Air

distribution also can be adjusted manually when wanted. The air conditioning is typically controlled automatically but can be switched on or off manually.

Air recirculation facilitates hold outdoor air from coming into the cabin and can cool the indoors extra speedy, but extended use may additionally motive window condensation, so go back to computerized mode while it's far not wanted.

3. Electric and Manual Windows

The

Sandero's

home windows may be operated manually or electrically, depending on the position. The manual rear home windows are opened or closed by using turning the manage to the preferred role. The electric the front windows work whilst the ignition is switched on and may be managed from the motive force's or passenger's switch.

Some fashions have one-contact operation, allowing the window to fully open or near with a quick press or pull of the switch, whilst urgent it again stops the motion. The rear electric windows also can be managed from the motive force's seat or the rear passenger controls, although they will no longer open completely.

A protection lock can be used to save you passengers from running the rear windows. If the only-contact function is temporarily disabled after repeated use, permit the machine to settle down earlier than operating it once more.

4. Luggage Compartment

The baggage compartment can be opened using the central locking system, the important thing or the committed button on the important thing or card, relying on the automobile. With the doors unlocked, press the luggage compartment button and raise the boot lid.

For guide establishing, insert the important thing into the boot lock, flip it and lift the lid. To near it, lower the boot lid using the cope with inside the bags

compartment, if geared up, and ensure not anything is blockading its movement. In very cold weather, the Dacia Sandero boot may be tough to open if the seals are frozen.

5. Transporting Objects in the Luggage Compartment

When sporting baggage or different objects, location the heaviest items at once on the floor and position them firmly in opposition to the rear seatbacks. If the rear seats are folded down, place the load towards the front seats to assist hold it solid.

Arrange the baggage in order that larger and heavier objects can't pass round at some point of driving. The to be had loading length relies upon at the vehicle model, with a most of about 1,053 mm for the four-door model and 790 mm for the 5-door model.

Maintenance

1. Bonnet

Dacia Sandero to open the bonnet, pull the release deal with from within the car, then carry the bonnet barely and release the protection capture. Raise the bonnet and secure it with the help live earlier than running within the engine compartment.

Make certain the windscreen wipers are in their parked role and take care to avoid harm while the bonnet is open. Before closing it, take a look at that nothing has been left inside the engine compartment. Return the assist live to its holder, decrease the bonnet to about 30 cm above the closed position, and launch it so that it locks securely underneath its own weight.

2. Engine Oil Level

It is normal for the engine to use a small amount of oil for lubrication and cooling, so the oil level ought to be checked frequently, especially earlier than a protracted adventure.

Park the vehicle on stage ground and test the oil with the dipstick after the engine has been switched off and allowed to chill.

The oil diploma ought to live between the minimum and most marks, as too little or an excessive amount of oil can harm the engine. When topping up, use the endorsed oil grade and add it cautiously to avoid spilling oil onto hot engine or electric additives. Wait around 20 mins after adding oil, then take a look at the extent once more with the dipstick. Always refit the dipstick and oil filler cap securely, and call an approved provider if the oil stage drops strangely or again and again.

3. Levels

Check the car's fluid levels often with the engine switched off and the vehicle parked on degree floor. The coolant degree ought to be checked when the engine is cold and must remain between the MINI and MAXI marks. Use only the advocated coolant for Dacia Sandero to assist defend the engine from freezing and corrosion..

The brake fluid level ought to also stay above the MINI mark, and any uncommon or repeated drop in stage or braking performance should be checked by way of an permitted supplier. For the windscreen washing machine fluid, open the reservoir cap and fill it with suitable washing machine fluid, the use of an anti-freeze type at some stage in wintry weather. Take care whilst operating near the engine because hot additives and the cooling fan can reason injury.

4. Battery

The battery can lose charge whilst the car is specifically used for brief trips, common town using, in bloodless climate, or whilst electric equipment such as the radio is used for a long term whilst the engine is switched off.

A weak battery may additionally have an effect on the Dacia Sandero operation of vital electrical systems, so normal checks are advocated. Battery replacement, elimination or disconnection ought to be performed via a certified professional to protect the car's electric gadget and make certain safety.

Keep the battery faraway from bare flames and smoking substances, defend your eyes while running close to it, and keep it out of reach of youngsters. The

battery consists of explosive and corrosive substances, so constantly follow the vehicle instructions and safety precautions.