

Driving

Driving Recommendation

Anticipate braking and hold a safe distance, particularly in bad climate. Never force with the parking brake carried out, as this will motive overheating and harm to the braking machine. Never leave youngsters or a car unattended at the same time as the engine is strolling. Do no longer run the engine in an enclosed location without proper air flow due to the fact the exhaust gases contain carbon monoxide and may be risky. If you want to power thru a flooded avenue, avoid it every time viable because water can harm the engine, gearbox and electrical systems.

If crossing is unavoidable, drive slowly with out stopping and do now not exceed 10 km/h. Do now not transfer off the engine even as crossing the flooded vicinity. After leaving the water, gently follow the brakes several instances when it is secure to assist dry the brake discs and pads. Stop the automobile earlier than wearing out any adjustment or different pastime that calls for your complete attention. During lengthy trips, take a ruin approximately every two hours.

Speed Manual Gearbox

To start the engine, practice the parking brake, choose impartial and fully press the grab pedal. Insert the key and turn it to the starting function without pressing the accelerator. Release the key whilst the engine starts offevolved. If the engine does not begin after some tries, prevent trying and contact a CITROËN dealer. To have interaction opposite tools, make sure the vehicle is absolutely stationary. Fully press the grab, improve the ring underneath the equipment knob and flow the gear lever to the left and forwards. To select fifth or sixth tools, flow the gear lever completely to the right before selecting the gear.

The Gear Efficiency Indicator recommends while to exchange gear to help reduce fuel intake. An arrow seems in the instrument panel to signify an upward or downward gear exchange. These tips are not compulsory; constantly choose the tools that suits the road and riding conditions. Hill Start Assist maintains the car desk bound for approximately seconds whilst starting on a slope. It gives the driver time to move from the brake pedal to the accelerator.

On an uphill slope, it really works with first equipment or impartial decided on. On a downhill slope, it works with reverse equipment selected. Do no longer depart the automobile while Hill Start Assist is keeping it. If a fault caution appears, have the gadget checked through a CITROËN provider or certified workshop.

Hill Start Assist

Hill Start Assist maintains the automobile desk bound for approximately two seconds when beginning on a slope. This offers the motive force time to move the foot from the brake pedal to the accelerator. The system works while the automobile is completely desk bound, the brake pedal is pressed, the desired slope situations are met and the driving force's door is closed. On an uphill slope, it really works while first tools or impartial is chosen.

On a downhill slope, it works while opposite tools is selected. Do now not leave the vehicle while Hill Start Assist is conserving it. If a person desires to leave the vehicle even as the engine is walking, follow the parking brake manually. Hill Start Assist cannot be switched off.