

Wheels & Care

Tyre Pressure Monitoring

Snow chains improve traction and braking on snow and ice, however they have to be appropriate to your Audi's wheel and tyre combination. Fit them handiest to the the front wheels, use first-class-hyperlink chains that do not protrude extra than nine mm, and force at no greater than 50 km/h or the decrease restrict required by means of nearby rules. Check their suit after visiting a short distance and cast off them while roads are clean of snow. Incorrect chains can damage the wheels or have an effect on automobile control, and that they should not be used if a defective air suspension leaves the automobile too low.

Low-profile tyres can improve managing, but they will produce more avenue noise, provide a more impregnable trip and go through damage extra without difficulty from potholes, kerbs and strong impacts. Keep them on the encouraged stress and investigate the tyres and rims often for cracks, bulges or other harm. Have any suspected damage checked through a certified workshop. The unfastened-wheel caution machine uses wheel sensors to locate viable unfastened wheel bolts and shows a warning within the tool cluster. If a warning appears, sluggish down carefully, prevent someplace safe and take a look at the wheel bolts. Have their tightening torque checked with a torque wrench as soon as viable.

The tyre strain loss indicator video display units adjustments in tyre rolling behaviour and warns you if stress may be too low or a fault is detected. Check the tyres every time a caution appears and save the ideal pressures in the gadget after changing tyre pressures or replacing wheels. Snow chains, damaged tyres, an ESC fault or failing to store up to date pressures can have an effect on the device's operation. Always comply with the car's encouraged tyre pressures and have continual warnings inspected.

Tyres, Wheels and Tyre Pressure Maintenance

Regularly check out your Audi's tyres and rims for cuts, cracks, bulges or different damage. Remove gadgets lodged within the tread and keep away from using over kerbs at sharp angles or immoderate speeds. Replace damaged tyres or wheels directly, and function any uncommon vibrations or adjustments in

copied with checked with the aid of a certified workshop. Tyre markings offer info which include width, profile, rim diameter, load index and velocity rating. For instance, 205/60 R16 92H indicates a tyre width of 205 mm, a 60% profile, a 16-inch rim diameter, load index 90 two and pace rating H. The production date is usually demonstrated through way of the very last 4 digits of the DOT code; as an instance, 2225 technique the tyre have emerge as made inside the 22nd week of 2025.

Fit new tyres in pairs on the same axle and pressure cautiously for the number one 500 km at the same time as they settle in. Avoid the usage of tyres older than six years in which viable, and use run-flat tyres most effective on vehicles designed for them. Check tyre pressure at least month-to-month and in advance than lengthy trips, with the tyres cold. Follow the pressure sticky label on the cause force's component B-pillar and regulate pressures regular with the vehicle's load. Save up to date pressures inside the automobile's machine after making changes.

Correct inflation permits decorate managing, braking, tyre existence and fuel overall performance. Check tread positioned on across all four tyres. Winter tyres decorate grip in bloodless, snowy and icy conditions and ought to be perfect to all four wheels. Replace them at the identical time as their tread reaches approximately 4 mm, and have a look at their most legal speed. Always use nicely matched wheel bolts and characteristic broken rims inspected by way of the use of way of a certified workshop.

Vehicle Washing and Paint Care

Regular cleaning allows guard your Audi's paintwork, hold its look and keep its charge. Remove hen droppings, insects, tree sap and street salt as rapid as viable, due to the reality those can damage the paint, mainly in hot weather. If using an automated vehicle wash, close to the house domestic windows and sunroof, switch off the wipers and fold in the outside mirrors as cautioned.

Check that your automobile's dimensions, ground clearance, wheels and any prepared add-ons are suitable for the car wash. A brushless wash is most important wherein available. When the usage of a excessive-strain purifier, follow the device commands, maintain the spray at least forty cm from the automobile

and keep away from directing it at seals, tyres, sensors, cameras, decals or electric additives. Do not spray electric factors inside the engine compartment.